

VOLUNTEERS INDUCTION

This list is by no means exhaustive but is designed to make people aware of the dangers of working on a site such as ours.

- Hard hats and High Viz vests to be worn at all times
Risk assessment WATRA 2, page 1
- Appropriate Personal Protective Equipment should be worn.
 - i.e. Gloves
 - Stout boots, preferably safety boots
 - Safety glasses or gogglesRisk assessment WATRA 2, page 1
- Always look out for passing members of the public and do not put them at risk from debris or tools on the towpath or when moving material. Stop work if there is a risk until members of the public are clear.
Risk assessment WATRA 1, page 2
- Always look out for plant or vehicles that might be moving or operating in the area.
Risk assessment WATRA 5, page 2
- Do not walk past or approach an item of plant before attracting the attention of the operator and then only approach when they indicate that it is safe to do so.
Risk assessment WATRA 5, page 2
- The conditions are likely to be very muddy and slippery, extra care to avoid slips and falls should be taken
Risk assessment WATRA 2, page 1
- Care should be taken to avoid trips and falls by tripping over cut or uncut undergrowth.
Risk assessment WATRA 2, page 1
- Care should be taken when entering the work site down canal banks.
Risk assessment WATRA 2, page 2
- Avoid heavy lifting or straining, seek help if required.
Risk assessment WATRA 3
- Extreme care must be taken when using hand tools to cut or clear debris to avoid hurting yourself or others.
Risk assessment WATRA 9
- Take and look out for buried objects including possible glass items buried in the undergrowth.
Risk assessment WATRA 16
- The burning of removed scrub will only be undertaken with the permission of the Wendover Arm Trust person in charge.
Risk assessment WATRA 16
- Any burning will be carried out under strict control and any fire must be supervised at all times
Risk assessment WATRA 16